

# Operation Manual

## Kayak Cart

51506

# toboli



Illustration similar, may vary depending on model

Read and follow the operating instructions and safety information before using for the first time.

Technical changes reserved!

Due to further developments, illustrations, functioning steps, and technical data can differ insignificantly.

Updating the documentation

If you have suggestions for improvement or have found any irregularities, please contact us.



The information contained in this document may alter at any time without previous notice. It is prohibited to copy or spread any parts of this document in any way without prior written allowance. All rights reserved.

The WilTec Wildanger Technik GmbH cannot be held accountable for any possible mistakes in this operating manual, nor in the diagrams and figures shown.

Even though, the WilTec Wildanger Technik GmbH has undergone biggest possible efforts to ensure that the operating manual is complete, faultless, and up to date, mistakes cannot be entirely avoided.

If you should find a mistake or wish to make a suggestion for improvement, we look forward to hearing from you.

Send an e-mail to:

[service@wiltec.info](mailto:service@wiltec.info)

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in various languages can be found in our online shop via:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH  
Königsbenden 12  
52249 Eschweiler  
Germany

To return orders for exchange, repair, or other purposes, please use the following address. Attention! To allow for a smooth execution of your complaint or return, it is important to contact our customer service team before returning the goods.

Returns Department  
WilTec Wildanger Technik GmbH  
Königsbenden 28  
52249 Eschweiler

E-mail: **service@wiltec.info**

Tel: +49 2403 55592-0

Fax: +49 2403 55592-15



## Introduction

Thank you for purchasing this quality product. **To minimise the risk of injury we urge that our clients take some basic safety precautions when using this device. Please read the operation instructions carefully and make sure you have understood its content.**

Keep these operation instructions safe.

## Parts list

Name	Quantity
Cart frame	1
Air wheel 25,4 cm (10")	2
Quick release pin	2
Tie down strap	1

## Assembly

- Unfold the cart frame and remove the quick-release pins from the axle by flipping the ring upwards and outwards.
- Slide one wheel onto each side of the axle.
- Secure the wheels by inserting the quick-release pins into the holes on the ends of the axle.
- Flip the R-ring over the ends of the axle to lock the wheels.

## Use

- Unfold the cart frame with the kickstand pointing in the direction in which the boat will be pulled.
- Place the boat onto the cart with its weight centred on the cart.
- Lift one end of the boat and pivot it, setting it down on the foam pads on the cart.
- Use the tie-down strap to secure the kayak to the cart. Do not overtighten the strap.
- Lift the end of the kayak, retract the kickstand, and roll the cart by pulling or pushing the kayak at walking speed.
- After use, clean the cart with fresh water and dry it lest it rust.

## Warnings!

- Do not exceed the kayak weight capacity of 45 kg (80 lbs.).
- Only roll the cart at walking speed. Do not tow the cart with motorised vehicles.
- Not for use by unsupervised children.

## Important notice:

The reprint or reproduction, even of excerpts, and any commercial use, even in part, of this instruction manual require the written permission of WilTec Wildanger Technik GmbH.