













No	Figure	Qty.	No	Figure	Qty.
1		1	7		1
2		1	8		2
3		1	9		1
4		1	10		2




5		2	11		1
6		1	12		1

A	B	C	D	E	F		
16+1	8+1	4+1	2+1	25+1	2+1	20	4







Step 3




Step 4




Step 5





Step 6



Step 7



Step 8



**Important notice:**

The reprint or reproduction, even of excerpts, and any commercial use, even in part, of this instruction manual require the written permission of WilTec Wildanger Technik GmbH.