










## 52417 – Outdoor Play Kitchen with Shelf and Sink

A 3.5×40		18								
B 3.0×25		42	①	②	③	④	⑤	⑥	⑦	⑧
C 3.5×30		4								
D 3.0×20		14								
⑨	⑩	⑪×2	⑫	⑬	⑭	⑮	⑯×2	⑰×4	⑱	⑲×2
									⑳	㉑





**Fetch thy pans and kettles! Take pot luck!**

Important note:

The reprint or reproduction, even of excerpts, and any commercial use, even in part of this instruction manual requires the written permission of the WilTec Wildanger Technik GmbH.