





52421 – Outdoor Playhouse for Children with Living Area and Patio


<ul style="list-style-type: none"> A 3.5x60 26x B 3.5x45 63x C 3.5x40 44x D 3.5x35 8x E 3.5x30 20x F 3.5x24 48x G 3.0x34 16x H 14x I 8x J 2x 	
<p style="text-align: center;">Step 1 Ax8</p>	<p style="text-align: center;">Step 2 Ex20</p>
<p style="text-align: center;">Step 3</p>	<p style="text-align: center;">Step 4 Bx8</p>



Step 5 | B×8




Step 6 | F×16 | H×4




Step 7 | B×11




Step 8 | A×4 | B×4 | J×2




Step 9 | A×4




Step 10 | F×12 | H×3




Step 11 | F×12 | H×3




Step 12 | A×2




Step 13 | A×8 | D×8




Step 14 | B×16




Step 15 | B×8




Step 16 | C×20




Step 17 | C×20




Step 18 | C×2



Step 19 | C×2



Step 20 | G×8 | F×4 | I×4 | H2



Step 21 | G×8 | F×4 | I×4 | H2

Important Note: Reproduction and any commercial use (of parts) of this operating manual, requires a written permission of WilTec Wildanger Technik GmbH.