





52421 – Casa juegos niños con salón y porche


<ul style="list-style-type: none"> A 3,5x60 26x B 3,5x45 63x C 3,5x40 44x D 3,5x35 8x E 3,5x30 20x F 3,5x24 48x G 3,0x34 16x H 14x I 8x J 2x 	<p> 1x2, 2, 3, 4, 5, 6x2, 7x2, 8, 9x2, 10, 11x2, 12, 13, 14, 15, 16, 17, 18x2, 19x2, 20, 21, 22x4, 23x4, 24x8, 25, 26x2, 27x4, 28x2 </p>
<p>Paso 1 Ax8</p>	<p>Paso 2 Ex20</p>
<p>Paso 3</p>	<p>Paso 4 Bx8</p>




Paso 5 | B×8




Paso 6 | F×16 | H×4




Paso 7 | B×11




Paso 8 | A×4 | B×4 | J×2




Paso 9 | A×4




Paso 10 | F×12 | H×3




Paso 11 | F*12 | H*3




Paso 12 | A*2




Paso 13 | A*8 | D*8



Paso 14 | B*16



Paso 15 | B*8



Paso 16 | C*20



<p>Paso 17 C×20</p>	<p>Paso 18 C×2</p>
<p>Paso 19 C×2</p>	<p>Paso 20 G×8 F×4 I×4 H2</p>
<p>Paso 21 G×8 F×4 I×4 H2</p>	

Aviso importante: La reimpresión de este manual, también parcial, así como cualquier uso comercial, incluso de algunas de sus partes, solo con autorización por escrito de la empresa WilTec Wildanger Technik GmbH.