

# User's manual

## Commercial Tin Can Opener

60312



Illustration similar, may vary depending on model

Read and follow the operating instructions and safety information before using for the first time.

Technical changes reserved!

Illustrations, functional steps, and technical data may deviate insignificantly due to continuous further developments.

Updating the documentation

If you have suggestions for improvement or have found any irregularities, please contact us.



The information contained in this document may alter at any time without prior notice. No part of this document may be copied or otherwise duplicated without prior written consent. All rights reserved. WilTec Wildanger Technik GmbH cannot be held liable for any possible mistakes in this operating manual, nor in the diagrams and illustrations shown.

Although WilTec Wildanger Technik GmbH has made every possible effort to ensure that this operating manual is complete, accurate, and up-to-date, errors cannot be ruled out entirely.

If you have found an error or wish to suggest an improvement, we look forward to hearing from you. Send us an e-mail to:

[service@wiltec.info](mailto:service@wiltec.info)

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in several languages can be found in our online shop:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH  
Königsbenden 12  
52249 Eschweiler – Germany

To return your goods for exchange, repair, or other purposes, please use the following address. Attention! To allow for a trouble-free complaint or return, it is important to contact our customer service team before returning your goods.

Retourenabteilung  
WilTec Wildanger Technik GmbH  
Königsbenden 28  
52249 Eschweiler – Germany

E-mail: **service@wiltec.info**  
Tel: +49 2403 55592-0  
Fax: +49 2403 55592-15



## Introduction

Thank you for choosing to purchase this quality product. To minimise the risk of injury, we ask you to always take some basic safety precautions when using this product. Please read this operating manual carefully and make sure that you understand it. Keep these operation instructions in a safe place.


## Safety instructions

- Only use the device according to the intended use defined in this manual. Every incorrect use might lead to injuries and damages.
- Only use the device on a level surface.
- Keep the device away from children. Do not leave children unattended when they are near the device.
- Never open cans that are under pressure.
- Avoid any contact with the knife. **Risk of injuries!**
- Never open cans that contain flammable goods (e.g., lighter fuel).
- Keep clothes, hair, and jewellery away from moving parts. **Risk of injuries!**
- Never remove or shift the knife.
- The device must not be operated if damaged or functionally impaired. If possible, ask a competent person to repair it.
- Thoroughly clean the device after every use. **Risk of damages to persons' health due to lacking hygiene!**
- To clean the device, never use abrasives, caustics, hard brushes, etc.
- Never reach for the can or lid during operation.
- Do not touch the lid cut off and the can opened directly at the edges cut.
- Pay attention when removing the cut off lid from the opener! The lid will turn as soon as pressure is applied.
- Keep your fingers, hair, jewellery, and clothes away from the rotating knife.
- Pay special attention when cleaning the knife. It is very sharp.
- No responsibility is accepted for damage caused by improper maintenance or use.

## Description

Thanks to its simple and quick operation as well as its robust design (cutting knife made of hardened steel/casing made of cast iron), the opener is suitable for both private and commercial use. The variable height allows the user to simply open quite large cans such as sausage cans.

## Operation



1. Before using the opener for the first time, clamp its base to a table or worktop using the screw clamp, then place the can that you wish to open onto the base.

With the handle put in vertical position, there is a gap between the cutting knife and body. The can must be placed so that the body can move downwards, allowing the knife to bore itself into the top part of the can and to cut an opening.

2. Now put the handle to horizontal position until the cutting knife is seated in the can, then turn it to the right. The can will turn as well until its top part is smoothly cut off. Make sure that the lid, once lifted, does not fall into the can.
3. Now put the handle to vertical position and remove the open can.



**Note:** After use, let the handle in the upright position so that the spring remains untightened and the device serves longer without problems.

### Important Note:

Reproduction and any commercial use (of parts) of this operating manual, requires a written permission of WilTec Wildanger Technik GmbH.