

# Operation Manual

## Nail Filing Machine

61488



Illustration similar, may vary depending on model

Read and follow the operating instructions and safety information before using for the first time.

Technical changes reserved!

Due to further developments, illustrations, functioning steps and technical data can differ insignificantly.

Updating the documentation

If you have suggestions for improvement or have found any irregularities, please contact us.



The information contained in this document may alter at any time without previous notice. It is prohibited to copy or spread any parts of this document in any way without prior written allowance. All rights reserved.

The WilTec Wildanger Technik GmbH cannot be held accountable for any possible mistakes in this operating manual, nor in the diagrams and figures shown.

Even though, the WilTec Wildanger Technik GmbH has undergone biggest possible efforts to ensure that the operating manual is complete, faultless and up to date, mistakes cannot be entirely avoided.

If you should find a mistake or wish to make a suggestion for improvement, we look forward to hearing from you.

Send an e-mail to:

[service@wiltec.info](mailto:service@wiltec.info)

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in various languages can be found in our online shop via:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH  
Königsbenden 12  
52249 Eschweiler  
Germany

To return orders for exchange, repair or for other purposes, please use the following address. Attention! To allow for a smooth execution of your complaint or return, it is important to contact our customer service team before returning the goods.

Returns Department  
WilTec Wildanger Technik GmbH  
Königsbenden 28  
52249 Eschweiler

E-mail: **service@wiltec.info**

Tel: +49 2403 55592-0

Fax: +49 2403 55592-15



## Introduction

Thank you for purchasing this quality product. **To minimize the risk of injury we urge that our clients take some basic safety precautions when using this device. Please read the operation instructions carefully and make sure you have understood its content.**

Keep these operation instructions safe.

## Safety notes

- Follow the instructions precisely. Only to be used for foot and finger nails, its intended purpose.
- Keep out of the reach of children.
- In case irritations or complaints occur, stop the application immediately.
- Ensure not to smoothen the nails too much. Do not use this device on thin, weak, damaged, or infected nails. Keep the device away from water.
- Never cover the device.
- Never leave the device running when unsupervised.
- The device is only disconnected from the electricity supply, when the mains adapter has been unplugged from the socket.
- Before connecting the device to the electricity supply, ensure that the voltage indicated on the type label matches with the voltage of the mains supply.
- Only use the device according to the purpose described in this operating manual.
- The device is not designed to be used for commercial purposes.
- Do not use spare parts which are not recommended by the manufacturer.
- Avoid contact with pointy or sharp objects. When using the device wrongfully, the warranty is voided.
- This device can be used by people, including children from the age of 8, with limited physical, sensory or mental abilities or lack of experience and knowledge, if they are supervised or have been instructed on how to use the device and understand the potential resulting dangers.
- Children need to be supervised when using the device, to ensure that they do not play with the device.
- Cleaning and user maintenance are not allowed to be carried out by children when they are unsupervised.

## Installation and electrical connection

- Connect the portable grinding head/hand piece to the “DC OUT” socket of the main panel.
- Select a proper drill bit according to the requirements and attach it to the hand piece.
- Turn the speed control knob to the left (towards minimum).
- Connect to the power supply.

## Operation

- Switch the power switch (the left switch on the panel) to “I.” The indicator will be illuminated, on and the machine is ready for operation.
- Push the switch (the right switch on the panel) to “+” or “-.” “+” is for a clockwise direction and “-” is for counter-clockwise direction.
- Press the red switch on the hand piece to turn it on.
- Adjust the speed control knob to control the rotation speed.
- Press the switch to “O” to switch off the hand piece.
- Press the power switch to “O” to turn off the machine.



## Technical specifications

<b>Main part (power supply and control)</b>	
<b>Rated voltage range (V)</b>	220–240
<b>Rated frequency (Hz)</b>	50
<b>Rated power input (W)</b>	12
<b>Rated output voltage (V)</b>	5–17 (DC)
<b>Hand/motor piece</b>	
<b>Working voltage (V)</b>	5–17 (DC)
<b>Rated current (A)</b>	1
<b>Rated speed (<math>\frac{1}{\min}</math>)</b>	0–20,000

## Operation instructions

- Do not change the turning directions too frequently. This will avoid damage to the hand piece.
- Turn the speed control counter clockwise to decelerate the grinding head to the minimum before turning off and switch the main power source to “o.”
- After operation put the grinding head onto the top of the main panel.
- While the grinding head is in operation, never pull out the 5-pin plug of the portable grinding head.
- For a long idle time please disconnect the power source.
- Any unauthorized disassembling of the product is prohibited. In case of any breakdown please contact the manufacturer or a qualified technician.
- If the supply cable is damaged it must be replaced by the manufacturer or a qualified technician to avoid a hazard.

## Disposal regulations

EU guidelines regarding the disposal of scrap electric appliances (WEEE, 2012/19/EU) were implemented in the law related to electrical and electronic equipment and appliances.

All WiTec electric devices that fall under the WEEE regulations are labelled with the crossed-out wheeled waste bin logo. This logo indicates that this electric equipment must not be disposed with the domestic waste.

The company WiTec Technik GmbH has been registered in the German registry EAR under the WEEE-registration number DE45283704.

Disposal of used electrical and electronic appliances (intended for use in the countries of the European Union and other European countries with a separate collection system for these appliances).

The logo on the article or on its packaging points out that this article must not be treated as normal household waste but must be disposed to a recycling collection point for electronic and electrical waste equipment. By contributing to the correct disposal of this article you protect the environment and the health of your fellow men. Environment and health are threatened by inappropriate disposal.



Material recycling helps reduce the consumption of raw materials.

Additional information on recycling this article can be provided by your local community, municipal waste disposal facilities or the store where you purchased the article.

Address:  
WiTec Wildanger Technik GmbH  
Königsbenden 12 / 28  
D-52249 Eschweiler

Important notice:

The reprint or reproduction, even of excerpts, and any commercial use, even in part, of this instruction manual require the written permission of WiTec Wildanger Technik GmbH.