




61596 – XXL Rabbit Hutch with Free Run




a1 – M6×40 24× 	a2 – M4×25 40× 	a3 – M3×16 36× 	a4 9× 	a5 4× 	a6 1× 	a7 1×
A – 1× 	B – 1× 	C – 1× 	D – 1× 	E – 1× 	F – 1× 	
G – 2× 	H – 2× 	I – 1× 	J – 1× 	K – 2× 	L – 2× 	
M – 2× 	N – 1× 	O – 1× 	P – 1× 	Q – 1× 	R – 2× 	




Step 1 – a1: 8× | a3: 4× | a4: 1×




Step 2 – a1: 8×




Step 3 – a1: 8×




Step 4 – a3: 32× | a4: 8×




Step 5 – a2: 20× | a5: 4×



Step 6 – a2: 8× | R: 2×



Step 7 – a2: 8× | a6: 1×



Step 8 – a2: 4×

Important Note:

Reproduction and any commercial use (of parts) of this operating manual, requires a written permission of WilTec Wildanger Technik GmbH.