Operation Manual

XXL Open Enclosure






Illustration similar, may vary depending on model

Please read and follow the operating instructions and safety information prior to initial operation.

Technical changes reserved!

Illustrations, functional steps, and technical data may deviate insignificantly due to continuous further developments.





The information contained in this document may alter at any time without prior notice. No part of this document may be copied or otherwise duplicated without prior written consent. All rights reserved. WilTec Wildanger Technik GmbH cannot be held liable for any possible mistakes in this operating manual, nor in the diagrams and illustrations shown.

Although WilTec Wildanger Technik GmbH has made every possible effort to ensure that this operating manual is complete, accurate, and up-to-date, errors cannot be ruled out entirely.

If you have found an error or wish to suggest an improvement, we look forward to hearing from you. Send us an e-mail to:

service@wiltec.info

or use our contact form:

https://www.wiltec.de/contacts/

The most recent version of this manual in several languages can be found in our online shop:

https://www.wiltec.de/docsearch

Our postal address is:

WilTec Wildanger Technik GmbH Königsbenden 12 52249 Eschweiler Germany

To return your goods for exchange, repair, or other purposes, please use the following address. Attention! To allow for a trouble-free complaint or return, it is important to contact our customer service team before returning your goods.

Retourenabteilung WilTec Wildanger Technik GmbH Königsbenden 28 52249 Eschweiler Germany

E-mail: **service@wiltec.info** Phone: +49 2403 55592-0 Fax: (+49 2403 55592-15)






Introduction

Thank you for choosing to purchase this quality product. To minimise the risk of injury, we ask you to always take some basic safety precautions when using this product. Please read this operating manual carefully and make sure that you understand it.

Keep these operation instructions in a safe place.


Assembly







Assembling the door









Parts lists

Name	Qty.	Name	Qty.
U bolt	4	M8×15 screws (door)	84
Roof	1	Wing screw	40
Rubber rope (roof)	1	Self-tapping M5.5×19 screw	
Wire for tying	1	Socket wrench 12/14 mm 8 mm (for self-tapping screw)	1 1
Cable tie	1	Cap for "G" part Cap for door	
M8 square head screw	20	Shaft bolt	
Nuts	20	Mesh wire (hexagon)	

Nº	Size (mm)	Figure	Quantity
1	1420		4
2	1260		6
3	990		4
4	1050		6
6–1	1110	*	1
6–2	850		1
7-1	1110	-	1
7-2	850		1
8	750	1	2
9	750		2
Α	580		2
В	480		4
С	1200		8
D		~	8
E		<u>+</u>	4
G		**	2
F			4
Н		★	8

<u>Important notice:</u> The reprint or reproduction, even of excerpts, and any commercial use, even in part, of this instruction manual require the written permission of WilTec Wildanger Technik GmbH.