**Operation Manual** 

Extension cord reel 62690, 62691, 62692





Illustration similar, may vary depending on model

Read and follow the operating instructions and safety information before using for the first time.

Technical changes reserved! Due to further developments, illustrations, functioning steps, and technical data can differ insignificantly.

Updating the documentation

If you have suggestions for improvement or have found any irregularities, please contact us.





The information contained in this document may alter at any time without previous notice. It is prohibited to copy or spread any parts of this document in any way without prior written allowance. All rights reserved.

The WilTec Wildanger Technik GmbH cannot be held accountable for any possible mistakes in this operating manual, nor in the diagrams and figures shown.

Even though, the WilTec Wildanger Technik GmbH has undergone biggest possible efforts to ensure that the operating manual is complete, faultless, and up to date, mistakes cannot be entirely avoided. If you should find a mistake or wish to make a suggestion for improvement, we look forward to hearing from you.

Send an e-mail to:

service@wiltec.info

or use our contact form:

https://www.wiltec.de/contacts/

The most recent version of this manual in various languages can be found in our online shop via:

https://www.wiltec.de/docsearch

Our postal address is:

WilTec Wildanger Technik GmbH Königsbenden 12 52249 Eschweiler Germany

To return orders for exchange, repair, or other purposes, please use the following address. Attention! To allow for a smooth execution of your complaint or return, it is important to contact our customer service team before returning the goods.

Returns Department WilTec Wildanger Technik GmbH Königsbenden 28 52249 Eschweiler

E-mail: **service@wiltec.info** Tel: +49 2403 55592–0 Fax: +49 2403 55592–15





## Introduction

Thank you for purchasing this quality product. To minimise the risk of injury we urge that our clients take some basic safety precautions when using this device. Please read the operation instructions carefully and make sure you have understood its content. Keep these operation instructions safe.

**Attention!** Abide by the information and instructions found within this operation manual to minimise the risk of injury and property damage. – Only for domestic use. Not for commercial use.

**Important!** Read these instructions carefully and thoroughly. Keep these instructions to refer to them later. If you give the product to anyone else, make sure you also to pass on this manual.

Keep small parts out of the reach of children. Pay special attention when unpacking it. Keep plastic bags and other packaging away from children. **Danger of suffocation!** 

Check all elements and parts for incompleteness and damages. Despite careful checks, even the best product could be damaged during transport. In this case, do not assemble it. Damaged parts can endanger your health.

Never modify the product! Changes will void the warranty and the product may be unsafe or even dangerous.

For cleaning use a sponge and warm soapy water. Do not use solvent-based cleaners of detergents, e.g., bleach. They can damage the product.

### Intended use

- The extension cord reel serves as a multi-extension to provide 230 V voltage where there are no power outlets. Only use the cable drum in closed rooms. Contact with moisture must be avoided.
- Only use the product for its intended purpose of use. Any modification applied by the customer will have an impact on its safety and cause danger. No responsibility will be taken for damage caused by improper handling or unappropriated use.

#### Safety instructions

- Before use, check that the power supply corresponds to that which is stated on the nameplate of the device. Avoid unintentional starting.
- Do not allow water of other liquids to get into the appliance. Do not expose it to rain.
- Do not use the appliance of the plug, the mains cable or other components are damaged. If the mains cable is damaged have the repair carried out by a qualified electrician to avoid a hazard. Never try to repair the appliance yourself. **Risk of electric shock!**
- Avoid pulling the cord when removing the plug from the socket. Hold the plug instead.
- Never plug in or unplug the mains plug when your hands are wet.
- The device is not intended for use by persons with physical, sensory, or mental restrictions or a lack of experience and/or knowledge of use unless they are supervised by a person responsible for their safety or have received instructions from that person on how to use the device. Children should be supervised to make sure that they do not play with the device.

#### Operation

If the cord drum is overheated, the built-in thermo-switch switches the whole cord drum off. Then disconnect the cable drum from the mains and disconnect the consumer load. Let the cable drum cool down, then press the thermo-switch on the cord drum.






#### Maintenance and care

- Clean the wire and main housing with a damp cloth.
- Do not spray water or any other liquid into the reel.
- Only have the reel repaired by a specialist. Check all parts for signs of wear. If any problems are detected, do not use the product. Always replace all damaged parts with original spare parts.
- If the product is not properly cared for and maintained, it can become unsafe and be damaged. This can lead to dangerous situations. Regular maintenance on the product helps to keep it safe and to increase its lifespan.
- Store the reel in a clean and dry place, out of the reach of children.

#### Parts list




Extension cord reel

Expansion bolt

#### Installation

- 1. Choose a location free of electrical wiring or other obstructions, making sure that the surface will be able to hold the hose reel.
- 2. Position the mounting bracket against the surface where you will fix it. Mark the holes for screwing the expansion bolts on the surface. It is advised to fix the reel at least 80 cm away from the floor.
- 3. Drill holes on the spots marked and ensure that the holes fit the expansion bolts.
- 4. Fix the mounting bracket to the wall with the expansion bolts provided.
- 5. Check that the hose extends and retracts smoothly.







# **Technical data**

		62690	62691	62692
Cable length (m)		10	15	20
Input cable length (m)		1.5		
Cable type		Ho5 VV-F 3G1.5mm <sup>2</sup>		
Power supply		230 V / 50 Hz		
Max. rated power (W)	Unreeled	2300		
	Reeled up	1000		
Protection code		IP20		
Operating temperature (°C)		-5-+55		





**i** 

EU guidelines regarding the disposal of scrap electric appliances (WEEE, 2012/19/EU) were implemented in the law related to electrical and electronic equipment and appliances.

All WilTec electric devices that fall under the WEEE regulations are labelled with the crossed-out wheeled waste bin logo. This logo indicates that this electric equipment must not be disposed with the domestic waste.

The company WilTec Technik GmbH has been registered in the German registry EAR under the WEEE-registration number DE45283704.

Disposal of used electrical and electronic appliances (intended for use in the countries of the European Union and other European countries with a separate collection system for these appliances).

The logo on the article or on its packaging points out that this article must not be treated as normal household waste but must be disposed to a recycling collection point for electronic and electrical waste equipment. By contributing to the correct disposal of this article you protect the environment and the health of your fellow men. Environment and health are threatened by inappropriate disposal.



Material recycling helps reduce the consumption of raw materials.

Additional information on recycling this article can be provided by your local community, municipal waste disposal facilities, or the store where you purchased the article.

Address: WilTec Wildanger Technik GmbH Königsbenden 12 / 28 D-52249 Eschweiler

Important notice:

The reprint or reproduction, even of excerpts, and any commercial use, even in part, of this instruction manual require the written permission of WilTec Wildanger Technik GmbH.