

# User's manual

## Fire Basket

62861

# toboli



Illustration similar, may vary depending on model

Please read and follow the operating instructions and safety information prior to initial operation.

Technical changes reserved!

Illustrations, functional steps, and technical data may deviate insignificantly due to continuous further developments.



The information contained in this document may alter at any time without prior notice. No part of this document may be copied or otherwise duplicated without prior written consent. All rights reserved. WilTec Wildanger Technik GmbH cannot be held liable for any possible mistakes in this operating manual, nor in the diagrams and illustrations shown.

Although WilTec Wildanger Technik GmbH has made every possible effort to ensure that this operating manual is complete, accurate, and up-to-date, errors cannot be ruled out entirely.

If you have found an error or wish to suggest an improvement, we look forward to hearing from you. Send us an e-mail to:

[service@wiltec.info](mailto:service@wiltec.info)

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in several languages can be found in our online shop:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH  
Königsbenden 12  
52249 Eschweiler Germany

To return your goods for exchange, repair, or other purposes, please use the following address. Attention! To allow for a trouble-free complaint or return, it is important to contact our customer service team before returning your goods.

Retourenabteilung  
WilTec Wildanger Technik GmbH  
Königsbenden 28  
52249 Eschweiler Germany




E-mail: **service@wiltec.info**  
Tel: +49 2403 55592-0  
Fax: +49 2403 55592-15

## Introduction


Thank you for choosing to purchase this quality product. To minimise the risk of injury, we ask you to always take some basic safety precautions when using this product. Please read this operating manual carefully and make sure that you understand it.

Keep these operation instructions in a safe place.

## Safety instructions

- Before operation, check the local prescriptions.
- The fire basket present is only suitable for outdoor use. Do not use it on wooden terraces.
- The fire basket present is only designed for burning logs and coal. Do not use any paper, leaves, and other flammable material.
- Keep children and animals away from the fire basket.
-  Only use the fire basket with caution, as it becomes hot during use. **Burning hazard!** Do not touch the hot fire basket bare-handed.
- Never leave a burning fire basket unattended and extinguish the fire completely before leaving the basket.
- Keep a minimum distance of 6 m between the fire basket and all flammable surfaces or buildings.
- Do not use the fire basket near flammable or highly flammable objects or materials.
- Only the chromed cooking grate is suitable for preparing food. The coal grate is not suitable for cooking and should not be used for this purpose.
-   Always wear gloves and protective goggles when filling the fire basket or extinguishing the fire.
- For emergency, hold a fire extinguisher ready near the fire basket.
- Place the logs onto the coal grate and light them with the help of a match. Do not overload the fire basket.
- During use, use the barbecue hook provided.

### **Warning!**

- Alcohol and/or medicine consumed might impair the ability to properly assemble and safely use the fire basket.
- When using the fire basket, take the same precautions as you would with any other open fire.
-  Never use the fire basket to heat interior rooms. Toxic carbon monoxide fumes might accumulate and cause choking fits or even death.

**Parts list**

**Note!** Before disposing of the packaging material, check it, as some components might be packed within the material.

Part	Name	Qty.	Figure
A	Spark arrestor hood	1	
B	Coal grate	1	
C	Fire Basket	1	
D1	Big supporting ring	1	
D2	Small supporting ring	1	
E	Legs	4	
F	Barbecue hook	1	
G	Hood ring	1	
H	Screw	12	
I	Cooking grate	1	

**Note!** A hexagonal wrench is required for assembly.

## Assembly

**Note!** Do not tighten the screws too much.

### Step 1

Mount the legs (**E**) to the big supporting ring (**D1**) with the help of the screws (**H**). Do not tighten the screws completely yet.



### Step 2

Now fix the small supporting ring (**D2**) to each leg (**E**) with the help of the screws (**H**), then tighten the screws.



### Step 3

Mount the spark arrester hood (**A**) with the help of the hood ring (**G**). Place the fire basket (**C**) onto the stand assembled, then place the coal grate (**B**) into the basket. Fix the spark arrester hood (**A**) onto the fire basket.



### Step 4

For barbecuing: Remove the spark arrester hood (**A**). Place the cooking grate (**I**) into the basket.



Important Note:

Reproduction and any commercial use (of parts) of this operating manual, requires a written permission of WilTec Wildanger Technik GmbH.