

Operating instructions

Dust Protection Wall

62966



Illustration similar, may vary depending on model

Read and follow the operating instructions and safety information prior to initial operation.

Technical changes reserved!

Illustrations, functional steps, and technical data may deviate insignificantly due to continuous further developments.

Updating the documentation

If you have suggestions for improvement or have found any irregularities, please contact us.



The information contained in this document may alter at any time without prior notice. No part of this document may be copied or otherwise duplicated without prior written consent. All rights reserved. WilTec Wildanger Technik GmbH cannot be held liable for any possible mistakes in this operating manual, nor in the diagrams and illustrations shown.

Although WilTec Wildanger Technik GmbH has made every possible effort to ensure that this operating manual is complete, accurate, and up-to-date, errors cannot be ruled out entirely.

If you have found an error or wish to suggest an improvement, we look forward to hearing from you. Send us an e-mail to:

service@wiltec.info

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in several languages can be found in our online shop:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH
Königsbenden 12
52249 Eschweiler – Germany

To return your goods for exchange, repair, or other purposes, please use the following address. Attention! To allow for a trouble-free complaint or return, it is important to contact our customer service team before returning your goods.

Retourenabteilung
WilTec Wildanger Technik GmbH
Königsbenden 28
52249 Eschweiler – Germany

E-mail: **service@wiltec.info**

Tel: +49 2403 55592-0

Fax: +49 2403 55592-15

Introduction

Thank you for choosing to purchase this quality product. To minimise the risk of injury, we ask you to always take some basic safety precautions when using this product. Please read this operating manual carefully and make sure that you understand it. Keep these operation instructions in a safe place.

The dust protection wall is flexible, as it can be mounted and installed according to the surface of the floor, requirements, or type of work to be done. After finishing the work, the user can simply unmount the dust protection wall and pack it for future use.

Installation

The dust protection wall is installed in a few minutes without the use of adhesive tape or screws; it will not leave any marks on the floor or ceiling.



Step 1



Step 2

Fix the plastic sheet to the upper cushion of the aluminium bars with the help of the end clamps.

Lift the first aluminium bar, the spring part pointing to the ceiling, then the other bars one after another.




Step 3



Step 4

Unlock the bar by turning the upper part anticlockwise. Now, adjust the length up or down and lock the bar.

With the help of the U clips, fix the sheet to the bars.




Step 5



Step 6

To create a passage: Fix the self-adhesive zip to the desired spot. Open the zip and cut the sheet.

After finishing work, pack all parts in the transport bag for future use.



No	Name/explanation	No	Name/explanation
1	Separation inside a room	4	Passage alongside the wall
2	Passage with double-zip	5	Passage with single zip
3	Room in the room		

Important note:

Reproduction and any commercial use (of parts) of this operating manual, requires a written permission of WilTec Wildanger Technik GmbH.