

# User's manual

## Automatic Watering System 62988

# toboli



Illustration similar, may vary depending on model

Please read and follow the operating instructions and safety information prior to initial operation.

Technical changes reserved!

Illustrations, functional steps, and technical data may deviate insignificantly due to continuous further developments.



The information contained in this document may alter at any time without prior notice. No part of this document may be copied or otherwise duplicated without prior written consent. All rights reserved. WilTec Wildanger Technik GmbH cannot be held liable for any possible mistakes in this operating manual, nor in the diagrams and illustrations shown.

Although WilTec Wildanger Technik GmbH has made every possible effort to ensure that this operating manual is complete, accurate, and up-to-date, errors cannot be ruled out entirely.

If you have found an error or wish to suggest an improvement, we look forward to hearing from you. Send us an e-mail to:

[service@wiltec.info](mailto:service@wiltec.info)

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in several languages can be found in our online shop:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH  
Königsbenden 12  
52249 Eschweiler Germany

To return your goods for exchange, repair, or other purposes, please use the following address. Attention! To allow for a trouble-free complaint or return, it is important to contact our customer service team before returning your goods.

Retourenabteilung  
WilTec Wildanger Technik GmbH  
Königsbenden 28  
52249 Eschweiler Germany

E-mail: **service@wiltec.info**  
Tel: +49 2403 55592-0  
Fax: +49 2403 55592-15

## Introduction

Thank you for choosing to purchase this quality product. To minimise the risk of injury, we ask you to always take some basic safety precautions when using this product. Please read this operating manual carefully and make sure that you understand it. Keep these operation instructions in a safe place.

## Parts



No	Name
1	Water intake
2	Water outlet
3	Fully digital display screen
4	Adjustments
5	Up (+)
6	Down (-)
7	Battery compartment (4 × AA batteries – not included)
8	USB connection (5 V)
9	Clip slot

Adjustments



№	Name / Function
1	Watering during a specific time interval (1 h–23 h, 1 day–30 d)
2	Watering length (1 s–99 s, 2 min–15 min)
3	Start of watering
4 / 5	Minutes and seconds
6	Hours
7	Adjustment: manual / automatic / stop
8	Numeric value up
9	Numeric value down
10	Keep adjustment button pressed and start manual watering.
11	Start of watering interval
12	Programming executed (flashes)
13	Battery power level
14	Days
15	Watering frequency (1 h–23 h, 1 d–30 d)

Scope of delivery



No	Name
1	Water pump
2	1/4" hose
3	1/4" dripper
4	Metal filter
5	Filter
6	End plug
7	Micro USB cable
8	1/4" fourfold plug
9	T piece

Installation



Step 1

Cut the hose to the desired length.



Step 2

Fix the T piece to the hose.



Step 3

Insert the dripper into one end of the water line.



Step 4

Install the filter head. Cut a portion of the hose to set the filter head in. Then insert into the water source.



Step 5

Connect the hoses to the water intake and outlet.



Step 6

Insert the dripper into the plant that should be watered.

## Regulations for waste disposal

The Waste Electrical and Electronic Equipment Directive (WEEE Directive, 2012/19/EU) of the EU was implemented in the German law related to electrical and electronic equipment and appliances.

All WilTec electric devices that fall under the WEEE directive are labelled with the symbol of a crossed-out wheeled rubbish bin. This symbol indicates that this electric device must not be disposed of with the domestic waste.

WilTec Technik GmbH is registered with the German registration authority EAR (Stiftung Elektro-Altgeräte Register) under the WEEE-registration number DE45283704.

Disposal of used electrical and electronic devices (intended for use in the countries of the European Union and other European countries with a separate waste collection system for these devices).

The symbol on the packaging or the product itself indicates that this product must not be treated as normal domestic waste but must be disposed of at a recycling collection station for electrical and electronic waste.

By disposing of this product correctly, you contribute to the protection of the environment and the health of your fellow people. Inappropriate disposal threatens the environment and health.



Material recycling helps to reduce the consumption of raw materials.

Additional information about the recycling of this product can be provided by your local commune, the municipal waste disposal facilities, or the store where you purchased the product.

Address:  
WilTec Wildanger Technik GmbH  
Königsbenden 12 / 28  
52249 Eschweiler Germany

### Important Note:

Reproduction and any commercial use (of parts) of this operating manual, requires a written permission of WilTec Wildanger Technik GmbH.