


A×50



B×48



C×44



D×8





1

x2

Ax4
Bx4
Cx4

2

x2

Ax4
Bx4
Cx4

3

x2

Ax2
Bx2
Cx2



<p>4</p>		<p>×2</p> <p>B×4</p>
<p>5</p>		<p>×2</p> <p>A×2</p> <p>B×2</p> <p>C×2</p> <p>D×4</p>
<p>6</p>		<p>×2</p> <p>A×4</p> <p>B×4</p> <p>C×4</p>



7

×2

A×2

B×2

C×2

8

A×14

B×4

C×4

Important Note: Reproduction and any commercial use (of parts) of this operating manual, requires a written permission of WilTec Wildanger Technik GmbH.