





64117 – Children's Play Kitchen with Accessories







<p>A</p> <p>x1</p>	<p>B</p> <p>x1</p>	<p>C x18</p>	<p>D x10</p>	<p>E x4</p>
<p>F x4</p>	<p>G</p> <p>x4</p>	<p>H</p> <p>x2</p>	<p>I</p> <p>x1</p>	<p>J</p> <p>x3</p>
<p>K</p> <p>x3</p>	<p>L x24</p>	<p>M</p> <p>x1</p>	<p>N x30</p>	<p>O</p> <p>x2</p>
<p>P</p> <p>x6</p>	<p>Q</p> <p>x1</p>	<p>R</p> <p>x1</p>	<p>S</p> <p>x2</p>	<p>X x 2</p>
<p>Z</p> <p>x3</p>	<p>Y x 2</p>			



H 	I 	J 	K 	L 	F 	O 	D
-------	-------	-------	-------	-------	-------	-------	-------

11

11

15

6



16




18






N 	c
-------	-------



11



13

















Important Note: Reproduction and any commercial use (of parts) of this operating manual, requires a written permission of WilTec Wildanger Technik GmbH.