wiltec



## Safety instructions

- Carefully study, understand, and follow all instructions before using the device.
- Observe warning notices to avoid personal injury and/or property damage.
- Do not exceed the specified load capacity.
- Use the ramp only on hard, flat surfaces to prevent slipping.
- Check the ramp for loose, bent, or damaged parts before each use.
- Do not use other lifting devices in conjunction with the ramps.
- Do not remove important vehicle components (e.g., brakes, engine) while the vehicle is on the ramps.
- Do not modify the ramps.
- Wear protective gear such as safety glasses and heavy-duty work gloves.
- Clean the ramps before each use to remove dirt and debris.
- Do not use ramps to support both ends of a vehicle or an entire side.
- Keep children away from the ramps.
- Avoid using the ramps under the influence of alcohol, drugs, or medication.
- The notes listed in this manual do not cover all possible situations. Always work with foresight and care.

## Use

- 1. Ensure that the wheels driven onto the ramps are aligned straight.
- Once the vehicle reaches the top of the ramp, another person located outside the danger zone must apply the brakes to prevent further advancement.
- 3. Please note that it is important not to accelerate or brake suddenly. Drive slowly and carefully.

- 4. The vehicle should first be shifted into neutral. Then release the brakes, the vehicle should not move. Finally, apply the parking brake. The vehicle should then be shifted into the park position (or into reverse gear for manual transmissions). Finally, block the wheels on the ground.
- 5. Ensure that the tyres are correctly positioned on the support platform of the ramp. Also, make sure that no persons are in the danger zone before the vehicle is shaken sideways and from end to end to ensure the stability of both vehicle and ramp. Check if the ramps have been damaged or bent during loading.
- 6. No modifications should be made at this point.

## **Technical data**

Item 63400

Material	HDPE
Dimensions (cm)	90.4 × 30.4 × 21.5
Lifting height (cm)	17
Lifting width (cm)	24,5

