

User's Manual

5-Door Mailbox System

60006–60008, 61744, 61754, 61760



Illustration similar, may vary depending on model

Read and follow the operating instructions and safety information before using for the first time.

Technical changes reserved!

Illustrations, functional steps, and technical data may deviate insignificantly due to continuous further developments.

Updating the documentation

If you have suggestions for improvement or have found any irregularities, please contact us.



The information contained in this document may alter at any time without prior notice. No part of this document may be copied or otherwise duplicated without prior written consent. All rights reserved. WilTec Wildanger Technik GmbH cannot be held liable for any possible mistakes in this operating manual, nor in the diagrams and illustrations shown.

Although WilTec Wildanger Technik GmbH has made every possible effort to ensure that this operating manual is complete, accurate, and up-to-date, errors cannot be ruled out entirely.

If you have found an error or wish to suggest an improvement, we look forward to hearing from you. Send us an e-mail to:

service@wiltec.info

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in several languages can be found in our online shop:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH
Königsbenden 12
52249 Eschweiler – Germany

To return your goods for exchange, repair, or other purposes, please use the following address. Attention! To allow for a trouble-free complaint or return, it is important to contact our customer service team before returning your goods.

Retourenabteilung
WilTec Wildanger Technik GmbH
Königsbenden 28
52249 Eschweiler – Germany

E-mail: **service@wiltec.info**


Tel: +49 2403 55592-0

Fax: +49 2403 55592-15

Introduction

Thank you for choosing to purchase this quality product. To minimise the risk of injury, we ask you to always take some basic safety precautions when using this product. Please read this operating manual carefully and make sure that you understand it. Keep these operation instructions in a safe place.

Technical drawing and parts list



Nº	Name	Nº	Name
1	Mailbox	7	Ring covers
2	Frame	8	Floor screws
3	Cross bars	9	Cross bar screws
4	Keys and locks	10	Spacer screws
5	Name plates	11	Mailbox screws
6	Spacers		

Assembly instructions

Choose a suitable location to place your mailbox system. Make sure that the surface is level and that you can anchor the frame firmly with the floor screws. We recommend that you assemble the mailbox close to where it is to be installed.

- Push the ring covers **(7)** onto the frame rods **(2)**. Check that the ring is pointing in the correct direction (see fig. 1).
- Connect the frame **(2)** and the cross bars **(3)** using the screws **(9)**. Leave the assembly loose and do not fully tighten the screws yet.
- Place the frame in the location that you have chosen and mark the mounting holes for the intended location (lift the ring covers to do this).
- Set the bracket aside and drill holes at the marked locations. Then you can attach the frame **(2)** with the floor screws **(8)**. Then connect the mailbox unit **(1)** to each other using the screws **(11)**.
- Now attach the mailboxes **(1)** with the spacers **(6)** between the bars of the frame **(2)**. Use the spacer screws **(10)** for this.
- Now tighten all the screws and finally attach the name tags **(5)** to the desired locations.



Figure 1

Technical specifications

	60006	60007	60008	61744	61754	61760
Total dimensions (mm)	585 × 270 × 385					
Dimensions of foot (mm)	1500 × Ø50	1500 × Ø50	1500 × Ø50	1500 × Ø50	1500 × Ø50	1500 × Ø50
Number of individual boxes	5					

Important Note:

Reproduction and any commercial use (of parts) of this operating manual, requires a written permission of WilTec Wildanger Technik GmbH.