

Operation Manual

Tyre Booster 19 ℓ/38 ℓ 62979, 62980



Illustration similar, may vary depending on model

Read and follow the operating instructions and safety information before using for the first time.

Technical changes reserved!

Due to further developments, illustrations, functioning steps, and technical data can differ insignificantly.

Updating the documentation

If you have suggestions for improvement or have found any irregularities, please contact us.



The information contained in this document may alter at any time without previous notice. It is prohibited to copy or spread any parts of this document in any way without prior written allowance. All rights reserved.

The WilTec Wildanger Technik GmbH cannot be held accountable for any possible mistakes in this operating manual, nor in the diagrams and figures shown.

Even though, the WilTec Wildanger Technik GmbH has undergone biggest possible efforts to ensure that the operating manual is complete, faultless, and up to date, mistakes cannot be entirely avoided.

If you should find a mistake or wish to make a suggestion for improvement, we look forward to hearing from you.

Send an e-mail to:

service@wiltec.info

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in various languages can be found in our online shop via:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH
Königsbenden 12
52249 Eschweiler
Germany

To return orders for exchange, repair, or other purposes, please use the following address. Attention! To allow for a smooth execution of your complaint or return, it is important to contact our customer service team before returning the goods.

Returns Department
WilTec Wildanger Technik GmbH
Königsbenden 28
52249 Eschweiler

E-mail: **service@wiltec.info**

Tel: +49 2403 55592-0

Fax: +49 2403 55592-15



Introduction

Thank you for purchasing this quality product. **To minimise the risk of injury we urge that our clients take some basic safety precautions when using this device. Please read the operation instructions carefully and make sure you have understood its content.**

Keep these operation instructions safe.

The tyre booster helps when a tubeless tyre cannot be inflated because the air between the tyre bead and rim edge can escape. Simply hold the tyre booster at an angle to the rim edge and release the air flow from the tyre booster. Due to the amount, the speed of the air and the angle at which the air is "shot" into the tyre, a vortex is created inside the tyre and the leak between the tyre bead and the rim edge is closed abruptly. Now the tyre can be inflated to the desired pressure.

Safety instructions

- Check the tyre booster for proper technical condition before using it.
- Fill the booster only with clean, dry, and oil-free compressed air.
- The air reservoir is equipped with a pressure control valve that opens at an air pressure of approx. 10 to 12 bar, which corresponds to the tested and recommended maximum working pressure.
- Do not alter or modify the air tank or other components of the booster. Modifications to the unit may result in serious injury.
- The specified maximum pressure must not be exceeded.
- The pressure tank may only be filled in normal ambient temperature. Avoid temperature fluctuations.
- Store the unit in a fully vented condition with the filling valve open.
- Only use the booster for its intended purpose.
- Never point the tyre booster at other people.
- Always wear appropriate hearing protection when operating this unit. Operating the booster without hearing protection can damage your ears and cause hearing loss as the impulsive, abrupt deflation process produces a noise level of more than 100 dB.
- Do not use flammable cleaning agents to clean the tyres when using the tyre inflation gun.
- Splinters, dust, or rust particles may be thrown around when deflating the booster. To avoid eye injuries, always wear protective goggles.

Application

- Close the locking valve and filling valve and connect the booster to the compressed air supply. Open the locking valve until the desired air pressure is reached. The pressure release valve opens at >10 bar.
- Place the inflation cone with its flange on the rim. Inflate the tyre by opening the inflation valve impulsively. Better results can be achieved if the tyre is inflated with a tyre inflator at the same time via the normal rim valve.
- Choose the angle so that the air can escape between the tyre and the rim. An angle too narrow/steep (at the rim/bead) significantly reduces the efficiency of the operation.

Storage and maintenance

Leave the filling valve open so that any moisture can escape. Regularly check the tank and all other components assembled for cracks and damage. Never loosen or tighten components with the tank being under pressure.

Important notice: The reprint or reproduction, even of excerpts, and any commercial use, even in part, of this instruction manual require the written permission of WiITec Wildanger Technik GmbH.