




Safety instructions

- Inspect the ramp before each use for visible damage, deformations, or material fatigue. Pay special attention to cracks, breaks, or worn areas.
- Ensure that the weight of the vehicle does not exceed the maximum load capacity of the ramp (3 tons). Overloading can damage the structure and lead to accidents.
- The ramp must be positioned on a stable and level surface. Avoid using the ramp on slippery, wet, or uneven surfaces.
- Ensure that the ramp is securely in place to prevent the vehicle from slipping off as it ascends.
- Drive slowly and steadily onto the ramp. Sudden movements or speeding can displace the ramp or destabilise the vehicle.
- Always wear recommended personal protective equipment such as safety shoes and gloves when working with the ramp.
- Ensure that the use of the ramp is always supervised to intervene immediately if any problems arise.
- Regularly clean the ramp and check it for wear.

Usage

1. Place the vehicle ramps as close as possible to the front of the tyres. Alternatively, you can place vehicle ramps as close as possible at the back of the tyres.



2. The ramps should be aligned with the wheels.



3. Slowly drive the vehicle (or reverse) with the assistance of a person outside the vehicle.



4. Engage the parking brake and place the jack under the vehicle.

