

Operation Manual

12 V Mini Pump

62543-62545



Illustration similar, may vary depending on model

Read and follow the operating instructions and safety information before using for the first time.

Technical changes reserved!

Due to further developments, illustrations, functioning steps, and technical data can differ insignificantly.

Updating the documentation

If you have suggestions for improvement or have found any irregularities, please contact us.



The information contained in this document may alter at any time without previous notice. It is prohibited to copy or spread any parts of this document in any way without prior written allowance. All rights reserved.

The WilTec Wildanger Technik GmbH cannot be held accountable for any possible mistakes in this operating manual, nor in the diagrams and figures shown.

Even though, the WilTec Wildanger Technik GmbH has undergone biggest possible efforts to ensure that the operating manual is complete, faultless, and up to date, mistakes cannot be entirely avoided.

If you should find a mistake or wish to make a suggestion for improvement, we look forward to hearing from you.

Send an e-mail to:

service@wiltec.info

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in various languages can be found in our online shop via:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH
Königsbenden 12
52249 Eschweiler
Germany

To return orders for exchange, repair, or other purposes, please use the following address. Attention! To allow for a smooth execution of your complaint or return, it is important to contact our customer service team before returning the goods.

Returns Department
WilTec Wildanger Technik GmbH
Königsbenden 28
52249 Eschweiler

E-mail: **service@wiltec.info**

Tel: +49 2403 55592-0

Fax: +49 2403 55592-15



Introduction

Thank you for purchasing this quality product. **To minimise the risk of injury we urge that our clients take some basic safety precautions when using this device. Please read the operation instructions carefully and make sure you have understood its content.**

Keep these operation instructions safe.

Product information

This pump convinces by newest technology, a stable product performance, a compact design, a light weight, and a versatile application possibility. The pump can be easily connected to a car battery.

Safety instructions

This device is not intended for use by persons (including children) with limited physical, sensory, or mental abilities or with lack of experience and/or knowledge, unless they are supervised or instructed by a person responsible for their safety on how to use this device. Children should be supervised to ensure that they do not play with the device.

- Perform a visual inspection of the appliance before each use. Do not use the device if safety devices are damaged or worn. Never override safety devices.
- Use the device only for the purpose specified in this manual.
- You are responsible for safety in the work area.
- If the cable or plug is damaged due to external influences, the cable must not be repaired! The cable must be replaced with a new one. This work may only be carried out by a qualified electrician.
- The voltage of 230 V AC specified on the type plate of the device must correspond to the existing mains voltage.
- Never lift or transport the device by means of the mains cable.
- Make sure that the electrical plug connections are protected from moisture and flood.
- Disconnect the device from the power supply before carrying out any maintenance or repair work.
- Do not expose the product to direct water jets or rain.
- The operator is responsible for compliance with local safety and installation regulations. Ask a qualified electrician if necessary.
- If the device should fail, repair work may only be carried out by a qualified electrician.
- The unit must never run dry or be operated with the suction pipe fully closed. Any damage to the unit caused by dry running will invalidate the manufacturer's warranty.


Warning! Read all safety instructions and instructions. Failure to follow the safety precautions and instructions may result in electric shock, fire, and/or serious injury. Keep all safety information and instructions in a safe place for future reference.

Commissioning

The temperature of the liquid pumped should not exceed +35 °C in continuous operation. The pumping of aggressive liquids (acids, lyes, silo leach etc.) as well as liquids with abrasive substances (e.g., sand) must be avoided. Also do not pump any highly flammable liquids (e.g., petrol) with this pump. The oil suction pump is suitable for a clean oil change or for pumping off engine, diesel, and heating oil.



Attention!

-  **Danger of explosion!** Do not pump petrol, petroleum, or other easily inflammable liquids!
- Ensure correct polarity when connecting the battery terminals!



- Always switch off the engine when vacuuming.
- Always heat engine oil before vacuuming!
- Never let the pump run dry. If the oil flow stops, switch off the pump immediately.
- Collect used oil in a sufficiently large container. Do not drain into the ground or sewage system! Dispose of the waste oil in the waste oil collection point!

Note: The oil suction pump is designed for an operating time of approx. 15 min. Then allow the unit to cool down.

Operating the oil suction pump

1. Before changing the oil, let the engine warm up until the oil temperature has reached approx. 40–60 °C.
2. Switch off the engine.
3. Connect the suction probe with suction hose to the suction port and the drain hose to the pump discharge port. To prevent the hoses from loosening, they are fixed with the enclosed hose clamps.
4. Insert the suction probe into the dipstick tube and push it to the lowest point of the oil pan.
5. Place the drain hose in a suitable container.
6. Now connect the oil suction pump to the battery. Pay attention to the correct polarity (black terminal on negative pole, red terminal on positive pole of the battery).
7. Switch on the pump and vacuum.
8. After completion of the suction process, switch off the pump again. Never let the pump run dry.
9. Fill your vehicle with new engine oil. Then check the oil level with the oil dipstick.

Note: After finishing the work, carefully clean the pump and accessories and store them in a dust-protected place.

Technical data

Item number	62543	62544	62545
Rated voltage (V)	12		
Rotation speed (1/min)	8700	8700	8500
Flow rate (1/min)	12	12	12–15
Delivery head (m)	3	3	2
Cable length (m)	3		
Outlet diameter (mm)	16	19	approx. 16
Outer diameter (mm)	38		

Disposal regulations

EU guidelines regarding the disposal of scrap electric appliances (WEEE, 2012/19/EU) were implemented in the law related to electrical and electronic equipment and appliances.

All WiTec electric devices that fall under the WEEE regulations are labelled with the crossed-out wheeled waste bin logo. This logo indicates that this electric equipment must not be disposed with the domestic waste.

The company WiTec Technik GmbH has been registered in the German registry EAR under the WEEE-registration number DE45283704.

Disposal of used electrical and electronic appliances (intended for use in the countries of the European Union and other European countries with a separate collection system for these appliances).

The logo on the article or on its packaging points out that this article must not be treated as normal household waste but must be disposed to a recycling collection point for electronic and electrical waste equipment. By contributing to the correct disposal of this article you protect the environment and the health of your fellow men. Environment and health are threatened by inappropriate disposal.



Material recycling helps reduce the consumption of raw materials.

Additional information on recycling this article can be provided by your local community, municipal waste disposal facilities, or the store where you purchased the article.

Address:
WiTec Wildanger Technik GmbH
Königsbenden 12 / 28
D-52249 Eschweiler

Important notice:

The reprint or reproduction, even of excerpts, and any commercial use, even in part, of this instruction manual require the written permission of WiTec Wildanger Technik GmbH.